

## RESISTANCE BUTT WELDING HEAD



### AIR WELDING HEAD

- Pressure reducer adjustable manually
- Forging sliding block set up on linear motion guides
- Lower jaw holders adjustable in X - Y
- Adjustment for butt resistance welding or brazing of different parts
- Adjustment for T-welding
- Head adjustable in assembling machine
- Butt welding machine
- Butt micro-welding

Head type	Steel wire's type	
BA	Microwelding	
BB	Ø 1 to Ø 3 mm	
BC	Ø 3 to Ø 8 mm	
BD	Ø 8 to Ø 16 mm	